


# HOW TO READ YOUR WATER METER

To check your bill, read only the four (4) white odometer wheels. They indicate units used in figuring your bill. A unit is 100 cubic feet which is the same as 748 gallons.

To look at your daily consumption, you can also read the two black odometer wheels on the right side of the register. They indicate tens and ones cubic feet.

To check for small leaks, check the triangle leak indicator at the center of the register. This will turn clockwise at very low rates of flow.



**NOTE:** Use care when lifting cover. The cover is heavy and is attached to an electronic device. Lift cover just above the level of the sidewalk and slide carefully to the side to read meter.

